
Control Panel

Home | News | Forums | Gallery | Classifieds | Wiki | Links | Mall ns Home Model-Lines Tech Talk More Car Talk Regional



Calendar

New Posts



Profile Page

Welcome, massboykie. You last visited: 08-14-2009 at 07:47 AM


Private Messages: Unread 1, Total 1. Forum Search Quick Links Log Out

B6/B7 S4/RS4 Discussion Forum relating to the B6 and B7 S4 and RS 4 (2003-2008). Sponsored by JHMotorsports


FAQ

Social Groups

IHITTOLD AS 20 ALS (209) 968-0077



Flat screwdriver
T25 Torks screwdriver (grinded to the diameter minimum, you will understand later why)



Using the flat screwdriver, snap off the clips: 5 of them



Pull off the rubber protector

1 This image has been resized. Click this bar to view the full image. The original image is sized 1024x683 and weights 74KB.



Install the headlight on a soft rag (prevent scratching the lens) and you are going to heat up the seal between the housing and the lens. No need to heat the entire perimeter, the glue used is messy enough when soft and you don't want it to stick to the chrome. Heat the area for 10 mn.

Materialized in red the area to be heated.





Now, grab two rags, hold the headlight vertically and separate the lens from the housing. The lens shape on the turn signal side provides a good grip. If it's too hard to pull, you can heat up a bit more the area.



Use a razor blade to cut the cold sealant.

1024x683 and weights 72KB.




Voila, headlight is open



Now you need to remove the internal housing. There are 3 screws holding it in place. Location materialized in red

1 This image has been resized. Click this bar to view the full image. The original image is sized 1024x683 and weights 97KB.






Close up of screw #2

1024x683 and weights 69KB.



Close up of screw #3



Now, the housing should slide off

1024x683 and weights 96KB.



On some headlights, it's a bit more difficult because the housing stays clipped in the turn signal area. Gently pry under the plastic tab to release it. Here is a close up of the tab that may stay clipped

↑ This image has been resized. Click this bar to view the full image. The original image is sized 1024x683 and weights 86KB.

Once the housing is removed, there is an additional screw to be removed right under the turn signal.

1 This image has been resized. Click this bar to view the full image. The original image is sized 1024x683 and weights 69KB.



At this stage, I have seen people banging the orange corner with the screwdriver: 99% of the time, you will end up breaking the turn signal tabs !!!

Now, the tricky screw: He is hiding behind the chrome housing. This is where I use my trimmed screwdriver and work it thru between the headlight housing and the chrome piece. Even if you scratch a bit the edge of the chrome housing, do not worry about it, you won't longer see it once the headlight is reassembled.



You can really see the sucker hiding on this one

1 This image has been resized. Click this bar to view the full image. The original image is sized 1024x683 and weights 79KB.



Now, you are going to separate the two plastic parts of the turn signal. Take a close look at the little plastic shaft preventing the separation



Using a razor blade, you are going to trim just a bit of the edge of the center pin, trying to make a chamfer.

1 This image has been resized. Click this bar to view the full image. The original image is sized 1024x683 and weights 64KB.



Once trimmed, it should look like this




And now, if trimmed enough, you will be able to slide and separate the 2 pieces.

1024x683 and weights 57KB.



And Voila



Now, to remove the orange cap, just push on it, towards the inside.

1024x683 and weights 79KB.



