



## Self-study Programme 396


# Lane Change Assist

Design and function



Lane change assist is a further technical innovation in driver assistance systems. This system is designed to prevent accidents.

This self-study programme explains how this kind of driver assistance system works in Volkswagen vehicles. The system informs and warns the driver about hazards when changing lane on motorways and dual-carriageways.



S396\_001

**NEW**



**Important Note**



**The self-study programme shows the design and function of new developments. The contents will not be updated.**

For current testing, adjustment and repair instructions, refer to the relevant service literature.



<b>Introduction</b> .....	<b>4</b>	A grey icon showing a person's head and shoulders next to an open book.
General description .....	4	
<b>Design</b> .....	<b>6</b>	An orange icon of a car with a white lightning bolt striking the top.
Components and their locations .....	6	
Components .....	8	
<b>Function</b> .....	<b>10</b>	An orange icon of a car with a white lightning bolt striking the top.
Monitoring procedure .....	10	
<b>Networking</b> .....	<b>14</b>	An orange icon of a car with a white lightning bolt striking the top.
Incorporation in the vehicle networking concept .....	14	
<b>Functional Diagram</b> .....	<b>16</b>	An orange icon of a car with a white lightning bolt striking the top.
<b>Service</b> .....	<b>18</b>	A green icon of a car with a white wrench positioned below it.
Diagnosis .....	18	
Calibration .....	20	
<b>Test Yourself</b> .....	<b>22</b>	A grey icon of a question mark.

# Introduction



## General description

### Situation


A frequent cause of accidents is failing to see vehicles when changing lanes on multi-lane roads. In 2005, there were approx. 5000 accidents involving personal injury and property damage that were caused partly by mistakes when changing lane.

Driver assistance systems can contribute to reducing accidents in these traffic situations and warn the driver about possible dangers in good time.

## Dangers when changing lane

### Blind spot

If a vehicle is travelling in the lane next to you, there is a danger that it is in the blind spot of the rear-view mirrors and you will therefore not see it when you change lane.



S396\_002




## Reducing risks when changing lane

The lane change assist monitors the space next to and behind the vehicle with the aid of radar beams. The driver will be informed if there is a vehicle in the monitored area or if a vehicle is approaching at a higher speed.

If the driver is planning to change lane in this situation and indicates this by activating the turn signal, the system will issue a warning.

The risk of accident is thus reduced by the lane change assist and therefore contributes to safety.



S396\_004

# Design

## Components and their locations

The components of the lane change assist and their locations are shown here using the Volkswagen Touareg as an example.



- Lane change assist warning lamp in driver side exterior mirror K233
- Lane change assist warning lamp in front passenger side exterior mirror K234
- Lane change assist control unit J769 is on the left-hand side behind the rear bumper.
- Lane change assist control unit 2 J770 is on the right-hand side behind the rear bumper.
- The button for driver assistance systems E617 is on the end of turn signal switch E2.

Lane change assist warning lamp in driver side exterior mirror K233.



Button for driver assistance systems E617 in turn signal switch E2



Lane change assist control unit J769 behind the bumper, left

Lane change assist warning lamp in  
front passenger side exterior mirror K234



Lane change assist control unit 2 J770  
behind the bumper, right

S396\_009




# Design

## Components

### Radar sensors


The radar sensors are configured as transmitter and receiver aerials which are in the control unit under a radome plastic cover.



### Button for driver assistance systems

The button for driver assistance systems E617 can be used to switch off the lane change assist. The icon on the button indicates the driver assistance systems.

Icon for driver assistance systems



Button for driver assistance systems E617



## Displays

### Highline dash panel insert

The lane change assist warning lamp K232 in the dash panel insert indicates that the lane change assist is active. The warning lamp is in the speedometer G21.

The systems status is indicated by the colour of the warning light:

- Green  
Lane change assist switched on and active  
(at speeds above 60 km/h)
- Yellow  
Lane change assist switched on and passive  
(at speeds below 50 km/h)

Lane change assist warning lamp K232



S396\_013



### Premium dash panel insert

The lane change assist warning lamp K232 in the dash panel insert indicates that the lane change assist is active. The warning lamp is located in the multifunction display.

The activation state is indicated by the colour of the warning light:

- Green  
Lane change assist switched on and active  
(at speeds above 60 km/h)
- Grey  
Lane change assist switched on and passive  
(at speeds below 50 km/h)

Lane change assist warning lamp K232




S396\_014

# Function

## Monitoring procedure

### Scanning area

The system detects dangers next to and behind the vehicle. The scanning area reaches from the B-pillar to approximately 50 m to the rear of the vehicle. The width of the scanning area is approx. 3.8 m.



### How it works:

The sensors in the control units monitor the scanning area and recognise objects that are in this area using radar waves. These objects are recognised by the respective lane change assist control unit (J769 or J770) and the time to a possible collision is calculated. The control unit calculates whether the object in the blind spot is at the same speed, is slowly dropping back or getting closer. If the calculated time falls below a set value, the driver is informed or warned when the turn signal is active.

## Information and warning

The information or warning that there is an object in the scanning area is provided by the lane change assist warning lamps in the exterior mirrors.

### Information

Information is provided when there is a danger, the lane change assist warning lamp on the corresponding side illuminates. It remains illuminated until the object leaves the scanning area.

Lane change assist warning light in driver side exterior mirror K233




S396\_011



### Warning

A warning is issued when the driver indicates his intention to change lanes by activating the turn signal in the direction of a detected object. This causes the lane change assist warning light on the corresponding side to start flashing. The warning is limited to a set time and then the system returns to information level. If the turn signal is left active after the original object poses no further danger and another object is detected another warning is issued. The warning is activated again if you switch the turn signal off and on again.




S396\_012

# Function

## Activation speed

The lane change assist is active at speeds above 60 km/h. Vehicles in the monitored area are recognised. The requirement for this is that the system is switched on with the button for driver assistance systems. If the speed falls below 50 km/h, the lane change assist switches to passive mode.




S396\_029



## Cornering

Vehicles are recognised on curves with over 200 m radius. On curves with smaller radii, the lane change assist switches to passive mode.

Radius > 200m




Radius < 200m



S396\_030

## Overtaking

When you overtake vehicles or they are falling behind, information or a warning is provided up to a speed difference of approximately 15 km/h. Above that no information on the object is displayed.




S396\_031



## Brightness of warning lamps

The driver can adjust the brightness of the lane change assist warning lamps using the customisation options. Furthermore the brightness is automatically adapted to the ambient light. The information for this is supplied by the rain and light sensor G397.



S396\_032

# Networking

## Incorporation in the vehicle networking concept

### Control units

The lane change assist consists of two control units:

- lane change assist control unit J769 and
- lane change assist control unit 2 J770.

The lane change assist control unit J769 is configured as the master control unit. The lane change assist control unit 2 J770 is the slave control unit. Both control units are linked to each other for data exchange via their own lane change assist private CAN data bus. The data transfer speed is 500 kbit/s.

The lane change assist control unit J769 is still a subscriber on the powertrain CAN data bus and can therefore receive all necessary CAN data bus messages for its functions.

When the ignition is switched off, the connection between the powertrain CAN data bus and the lane change assist control unit is disconnected by the cut-off relay for safety reasons.




### CAN data bus messages

The following CAN data bus messages are required for trouble-free operation of the lane change assist:

#### Message

- Airbag control unit J234  
Storage of warning lamp statuses
- ABS control unit J104  
Provision of speed and yaw rate signal
- Control unit with display in dash panel insert J285 and data bus diagnostic interface J533  
Display of activation statuses  
Forwarding all CAN data bus messages
- Onboard supply control unit J519  
Provision of turn signals
- Trailer detector control unit J345  
Indication of whether a trailer is attached and, if necessary, deactivation of the lane change assist
- Wiper motor control unit J400  
Provision of the signal from the rain and light sensor G397 and adjustment of the brightness of the lane change assist warning lamps
- Entry and start authorisation control unit J518  
Provision of the remote key signal for customisation

## Overview of network




S396\_015

### Legend

G397	Rain and light sensor	J533	Data bus diagnostic interface
J104	ABS control unit	J769	Lane change assist control unit
J234	Airbag control unit	J770	Lane change assist control unit 2
J285	Control unit with display in dash panel insert	J788	Cut-off relay for CAN powertrain bus
J345	Trailer detector control unit	K233	Lane change assist warning lamp in driver side exterior mirror
J400	Wiper motor control unit	K234	Lane change assist warning lamp in front passenger side exterior mirror
J518	Entry and start authorisation control unit		
J519	Onboard supply control unit		
J527	Steering column electronics control unit		



# Functional Diagram




S396\_016

## Legend

- J769 Lane change assist control unit
- J770 Lane change assist control unit 2
- K233 Lane change assist warning lamp in driver side exterior mirror
- K234 Lane change assist warning lamp in front passenger side exterior mirror
- S Fuse





S396\_017

### Legend

- E617 Button for driver assistance systems
- G397 Rain and light sensor
- J119 Multifunction display
- J285 Control unit with display in dash panel insert
- J345 Trailer detector control unit
- J400 Wiper motor control unit
- J527 Steering column electronics control unit
- J533 Data bus diagnostic interface
- J788 Cut-off relay for CAN powertrain bus
- K232 Lane change assist warning lamp
- S Fuse
- V Windscreen wiper motor



## Diagnosis

### Diagnosis functions

The following diagnosis functions are possible with the VAS diagnosis testers:

- Identification of control units
- Query fault memory
- Delete fault memory
- Read data blocks
- Control element test
- Basic setting
- Customisation
- Code

The individual diagnosis functions are available via the guided fault finding system or the guided functions.

VAS 5051B



S396\_018



VAS 5052



S396\_024


VAS 5053



S396\_025

## Fault finding


Fault-finding programs are available in the guided fault finding system for use with the lane change assist.



S396\_027

## Testing individual components

Individual component tests can be called up via the function and component selection in the guided fault finding system.



S396\_028



## Calibration

To work correctly, the lane change assist needs to be calibrated after the following work on the vehicle:


- One of the two lane change assist control units is replaced
- The location of one of the two lane change assist control units is changed
- Body repairs are performed at the rear
- Removal or repositioning of the rear bumper

During calibration, radar beams are emitted that are reflected by the Doppler simulator. This simulates a vehicle. Since the Doppler simulator has a defined position, a certain number of radar beams are expected in a set time.

Deviations indicate that the control units are not in the correct position.

These deviations are displayed on the VAS diagnosis tester.

The calibration procedure is described in the workshop manual in ElsaWin.



S396\_026

## Required special tools

### Calibration unit

The calibration unit is part of the VAS 6350 tool set and is also required to calibrate the reversing camera.




S396\_019

### Doppler simulator

The VAS 6350/4 Doppler simulator is equipped with reflector plates. This simulates a driving vehicle. The system is powered with mains voltage.

The package includes:

- a Doppler simulator VAS 6350/4
- a holding post VAS 6350/4-1
- a post mounting, left VAS 6350/4-2
- a post mounting, right VAS 6350/4-3



S396\_023



The VAS 6350 tool set still includes the wheel centre mountings, the spacing laser and the linear laser.

# Test Yourself

---

**1. Which statement about the lane change assist control units is correct?**

- a) The lane change assist control unit J769 is used as a slave control unit.
- b) The lane change assist control unit 2 J770 is used as a slave control unit.
- c) The lane change assist control units are identical.
- d) The lane change assist control unit 2 J770 forms the interface with the convenience CAN data bus.

**2. Which statement is correct?**

The lane change assist is active at

- a) speeds above 60 km/h.
- b) speeds above 50 km/h.
- c) speeds above 60 km/h if the system has been switched on by the driver with the button for driver assistance systems.
- d) speeds above 50 km/h if the system has been switched on by the driver with the button for driver assistance systems.

**3. When do the lane change assist control units need to be calibrated?**

- a) during every inspection service
- b) during every regular service
- c) when the rear bumper is removed
- d) when one of the two control units is replaced



**4. Where are the transmitter and reception aerials for the lane change assist?**


- a) in the exterior mirrors
- b) in the lane change assist control unit J769 on the left-hand side
- c) in the lane change assist control unit J770 on the right-hand side
- d) in the rear parking aid senders (G203 - G206)

**5. How is the passive mode of the lane change assist indicated in the Highline dash panel insert?**

- a) The lane change assist warning lamp K232 is green.
- b) The lane change assist warning lamp K232 is grey.
- c) The lane change assist warning lamp K232 is yellow.
- d) The lane change assist warning lamps K233 and K234 are constantly illuminated.



Answers:  
1 b; 2 c; 3 c, d; 4 b, c; 5 c



© VOLKSWAGEN AG, Wolfsburg  
All rights and rights to make technical alterations reserved.  
000.2811.86.20  
Technical status 06.2007

Volkswagen AG  
Service Training VSQ-1  
Brieffach 1995  
38436 Wolfsburg