Thread Tools ♥ Display Modes ♥

#1







Audizine Forums > Tech Forums > DIY How-To's  B7 A4 2.0T: K04 Turbo Installation		User Name Remember Me? Password Log in
Register	FAQ	Calendar

DIY How-To's Share and discover Do-It-Yourself How-Tos for your vehicle, ranging from the very simple to the quite complex

# Post Reply

Four Rings

Registered User

Join Date: Sep

AZ Member#:

18 2006

Location: Sydney Australia

My Garage:

2008 Audi S5, 2007 VW Golf

11649

R32

02-01-2007, 06:07 AM B7 A4 2.0T: K04 Turbo Installation <u>mrponline</u>

## K04 Turbo Installation Write Up

The K04 kit comes with everything you need (except tools). Every gasket, nut, bolt and screw that is removed in order to get the K03 off and the K04 on is supplied within the kit. It is not recommended that you drive the car with either the K04 turbo and K03 programs or vice versa. So it is a good idea to have your ECU flashed with the K04 programs prior to installing the KO4 by removing the ECU and sending it in to APR (see my ECU Removal Write Up).

The K04 Install write up assumes that the front of the car is jacked up and the CAI (OEM, Carbonio or other), Cat Converter or Test pipe and both plastic trays (underneath the car) are already removed. Im sure you can find other DIY write ups on how to remove these but if you cant manage to get these simple components off then I do not recommended that you take on the K04 install yourself even though this write up is fairly comprehensive.

### Tools / Parts Required

- Torx #55 (Either socket or allan key) The shorter the better as this is used in a very tight spot see step #11.
- Metric in hex socket set and insert bits (5mm -> 10mm)
- 19mm Hose with end plug.
- Assorted sized pliers, multigrips, spanners, screwdrivers, sockets and ratchets.


#### My Photo Gallery

▶ My Reputation:

## The KO3 Ready To Go - Installation time 4 - 6 hours.

It is a good idea to block the air input and output parts of the KO3 with the red plugs that APR supply on the KO4. The last thing you need is anything falling into them.













Step #3
Undo the clap and remove the hose from coolant line that goes into the manifold this is a slight PITA as there very little space. Long pointy pliers will do the trick.












Metal guard removed







And also undo the plastic plug from the bracket in order to move the wires up into the engine bay and out of the way.






Step #9
Remove the oil line from the engine block that runs into the turbo.

Have a rag handy as the oil from the line will leak out. This is a very minimal amount.



Step #10
The oil return line from the turbo to the sump is removed on the turbo end. Not much space to manovour here.






Step #11

Now for the hardest part you need a Torx #55 insert bit to remove this. This is the coolant input line and there is very little space to move around. The reason we remove it from the turbo end and not from the engine block is that we want to minimise the amount of coolant leaking out. More importantly we need to make sure that the manifold end is plugged (see step #3).

At this point we only want to **loosen** this bolt by removing it coolant will start to trickle out (gush out if step #3 hasent been performed) Loosen the bolt from the top as shown on the first picture below.





Follow the line underneath the K03 and you will come across a bracket thats attached to the coolant line remove the



Step #12
The manifold has 4 nuts on the bottom, these just need to be loosened and not removed as they hold 2 metal plates which wedges the bottom of the turbo manifold to the engine. The top 5 nuts need to be removed.



Now try to get everything out of the way totally undo the bolt that was loosened in step #11 (coolant will start to trickle out) and carefully lift up the K03 and pull it towards yourself of the engine block. Now carefully start to pull it out of the engine without catching it on other pipes / electrical components.

Once its out you need to hang the turbo coolant line (thats trickling) onto one of the manifold bolts this will be high enough so no more coolant will leak out.




Step #13

Now you need to move all the plumbing (2 oil lines, 1 coolant line, 1 vacuum line) and the turbo bracket from the K03 (pictured right) to the K04 (pictured left). Also part of the K04 kit are some insert screws that need to be put onto the K04 (Exhaust end) so you can mount your cat or testpipe.







Audizine is an independently owned and operated automotive enthusiast community and news website.

Audi and the Audi logo(s) are copyright/trademark Audi AG. Audizine is not endorsed by or affiliated with Audi AG.