



# Cabin Filter Installation Guide



**BOSCH**

**en Cabin Air Filter**  
Fitting Instructions

**es Filtro de habitaculo**  
Instrucciones de montaje

**fr Filtre d'habitacle**  
Notice de montage

## Fitting Instructions

Cabin Filter

## Instrucciones de montaje

Filtro de habitaculo

## Notice de montage

Filtre d'habitacle

---

### VW Passat B5 from 1997-2000; Audi A4 from 1995-2000

## P3740, C3740

Replacement interval 15.000 km/10,000 miles or after 12 months

Intervalo de cambio 15.000 km o despues de 1 año

Intervalle de remplacement 15.000 km ou une fois par an

Assembly is the reverse order of operation

Para concluir la instalacion, seguir el orden inverso

Le remontage s'effectue dans l'ordre inverse

1. Tools needed are a Phillips screwdriver. Open the hood. Notice the cover for the cabin filter is on the cowl on the passenger side. Remove the screw from the cover.
2. Remove the cover by pulling toward the front of the vehicle. The filter is now visible.
3. Remove by pushing up on the filter to loosen from housing and then pulling out toward the front of the vehicle.
4. Replace with clean cabin filter. Replace cover by lining up the notches on either side of the cover plate to the grooves in the filter housing. Replace the screw in the cover plate.

**Fitting Instructions**

Cabin Filter

**Instrucciones de montaje**

Filtro de habitaculo

**Notice de montage**

Filtre d'habitacle

**Audi A6 (C4) from 1995-1997;  
Audi A6 (C5) from 1998-2000****P3873, C3873  
P3800, C3800**

Replacement interval 15.000 km/10,000 miles or after 12 months







Intervalo de cambio 15.000 km o despues de 1 año

Intervalle de remplacement 15.000 km ou une fois par an

Assembly is the reverse order of operation

Para concluir la instalacion, seguir el orden inverso

Le remontage s'effectue dans l'ordre inverse

**1. 1994-1997****2. 1994-1997****3. 1997-2000****4. 1997-2000****5. 1994-1997****6. 1994-1997**

## Fitting Instructions

Cabin Filter

## Instrucciones de montaje

Filtro de habitaculo

## Notice de montage

Filtre d'habitacle

---

### Audi A8 from 1994-2003

### Audi A8 from 1994-2002

## P3803, C3803

Replacement interval 15.000 km/10,000 miles or after 12 months

Intervalo de cambio 15.000 km o despues de 1 año

Intervalle de remplacement 15.000 km ou une fois par an

Assembly is the reverse order of operation

Para concluir la instalacion, seguir el orden inverso

Le remontage s'effectue dans l'ordre inverse

1. Open hood.
2. Locate filter housing on underside of hood. Press in quick lock retainer and turn 90° degrees.
3. Remove the cabin filter by pulling it straight down.  
Install a new cabin filter.
4. Replace housing. Press in quick lock retainer and turn.

**Fitting Instructions**

Cabin Filter

**Instrucciones de montaje**

Filtro de habitaculo

**Notice de montage**

Filtre d'habitacle

**VW Beetle from 1998****C3854**

Replacement interval 15.000 km/10,000 miles or after 12 months

Intervalo de cambio 15.000 km o despues de 1 año

Intervalle de remplacement 15.000 km ou une fois par an

Assembly is the reverse order of operation

Para concluir la instalacion, seguir el orden inverso

Le remontage s'effectue dans l'ordre inverse

1. Tools needed are a hex head screwdriver. Depress the two clips on the cover plate in the middle of the dash and remove.



2. Remove the screws in the middle and on the passenger side of dash. Take out the passenger side of the dash plate. Unplug the dash light.



3. Remove the six screws in the filter cover. Lift out the filter and frame by depressing tab at front left corner.



4. Remove the filter from the frame and replace with a clean cabin air filter. Reinsert filter and frame, and snap into place. Replace passenger side of dash and plug in dash light. Push dash cover plate into place.



**Fitting Instructions**

Cabin Filter

**Instrucciones de montaje**

Filtro de habitaculo

**Notice de montage**

Filtre d'habitacle

**VW Golf A3 from 1993-1997;  
VW Passat B6 from 2001;  
Audi TT from 2000**

**P3852, C3834**

Replacement interval 15.000 km/10,000 miles or after 12 months

Intervalo de cambio 15.000 km o despues de 1 año

Intervalle de remplacement 15.000 km ou une fois par an

Assembly is the reverse order of operation

Para concluir la instalacion, seguir el orden inverso

Le remontage s'effectue dans l'ordre inverse

1. Tools needed are a Phillips screwdriver. Open the hood. Remove weather stripping from the passenger side. Remove four screws from the cabin filter cover.



2. Remove cover by pulling towards front of vehicle.



3. Remove filter and top filter housing plate by depressing the two tabs on the top housing plate. Lift filter and pull out. Remove used filter from top housing plate and replace with clean cabin filter.



4. Make sure to line up the four notches on the top side of the filter with the ribs on the top housing plate. Replace filter and top housing plate by sliding into place and pushing down until the two tabs click into place. Reattach cover.



**Fitting Instructions**

Cabin Filter

**Instrucciones de montaje**

Filtro de habitaculo

**Notice de montage**

Filtre d'habitacle

**VW Passat from 1993-1997****P3780, C3781**

Replacement interval 15.000 km/10,000 miles or after 12 months





Intervalo de cambio 15.000 km o despues de 1 año

Intervalle de remplacement 15.000 km ou une fois par an

Assembly is the reverse order of operation

Para concluir la instalacion, seguir el orden inverso

Le remontage s'effectue dans l'ordre inverse

**1. 1995-1996****2. 1995-1996****3. 1993-1994****4. 1993-1994****5. 1995-1996**

**Fitting Instructions**

Cabin Filter

**Instrucciones de montaje**

Filtro de habitaculo

**Notice de montage**

Filtre d'habitacle

**VW Golf from 1998-2003;  
VW Jetta from 1999-2002****C3854**

Replacement interval 15.000 km/10,000 miles or after 12 months  
Intervalo de cambio 15.000 km o despues de 1 año  
Intervalle de remplacement 15.000 km ou une fois par an

Assembly is the reverse order of operation  
Para concluir la instalacion, seguir el orden inverso  
Le remontage s'effectue dans l'ordre inverse

1. Tools needed are a Phillips screwdriver. Remove weather stripping from passenger side. Remove four screws from cabin filter cover.




2. Remove cover by pulling towards front of vehicle.



3. Remove filter and top filter housing plate by depressing the two tabs on the top housing plate. Lift filter and pull out.



4. Remove used filter from top housing plate and replace with clean cabin filter. Make sure to line up the four notches on the top side of the filter with the ribs on the top housing plate. Replace filter and top housing plate by pushing it down until the two tabs click into place. Reattach cover.





**Fitting Instructions**

Cabin Filter

**Instrucciones de montaje**

Filtro de habitaculo

**Notice de montage**

Filtre d'habitacle

---

**VW Toureg from 2003****C3861**

Replacement interval 15.000 km/10,000 miles or after 12 months

Intervalo de cambio 15.000 km o despues de 1 año

Intervalle de remplacement 15.000 km ou une fois par an

Assembly is the reverse order of operation

Para concluir la instalacion, seguir el orden inverso

Le remontage s'effectue dans l'ordre inverse

1. Tools needed are a Phillips screwdriver. Filter is located in front passenger footwell.
2. Remove footwell trim on front passenger side.
3. Remove the screws on the left and right of the compartment cover. Remove cover. Filter can be removed by pulling straight down.
4. Replace with a cabin air filter. Replace cover and reinsert the screws. Replace footwell trim.