



2004 Maintenance Schedule A4/S4/Cabriolet

	Miles	5	15	25	35	45	55	65	75	85	95
Kilometers	8	25	40	55	70	85	100	115	130	145	145
Engine Oil – change oil and replace filter		•	•	•	•	•	•	•	•	•	•
Wiper/Washer/Headlight washer – check adjust. and function		•	•	•	•	•	•	•	•	•	•
Tires and Spare – check condition, pressure		•	•	•	•	•	•	•	•	•	•
Tires – rotate		•									
Service Reminder Display – reset		•	•	•	•	•	•	•	•	•	•
Road Test		•	•	•	•	•	•	•	•	•	•
Cooling System – check level, add if necessary			•		•		•		•		•
Exhaust System – check for damage, leaks			•		•		•		•		•
Engine OBD – check memory, purge			•		•		•		•		•
Engine – check for leaks			•		•		•		•		•
Snow Screen for Air Cleaner – clean (1.8T and 3.0)			•		•		•		•		•
Battery – check electrolyte, add if necessary			•		•		•		•		•
Dust and Pollen Filter – replace			•		•		•		•		•
Automatic Transmission and Final Drive – check for leaks			•		•		•		•		•
Manual Transmission and Final Drive – check for leaks			•		•		•		•		•
Sunroof – clean, lubricate rails			•		•		•		•		•
Front Axle – check dust seals, ball joints, tie rods, tie rod ends			•		•		•		•		•
Tire Repair Set – check renewal date			•		•		•		•		•
Lights – check			•		•		•		•		•
Headlights – inspect, adjust if necessary			•		•		•		•		•
Brake System – check			•		•		•		•		•
Drive Shaft Boots – check			•		•		•		•		•
Door Hinge Mechanisms – lubricate			•		•		•		•		•
Spark Plugs – replace (1.8T and 3.0)					•				•		
Spark Plugs – replace (S4)							•				
Multitronic™ Transmission – change ATF					•				•		
Power Steering Fluid – check, add if necessary					•				•		
Air Cleaner – clean housing, replace filter element							•				
Ribbed Belt – replace (1.8T and S4)									•		
Ribbed Belt – check (3.0)									•		
Timing Belt – replace (1.8T and 3.0)									•		

Brake Fluid – replace every 2 years, regardless of mileage

Cloth Top – check function and roll-over protection with cloth top down (Cabriolet) every 2 years, regardless of mileage



2004 Maintenance Schedule A6/allroad

	Miles	5	15	25	35	45	55	65	75	85	95
Kilometers	8	25	40	55	70	85	100	115	130	145	145
Engine Oil – change oil and replace filter	•	•	•	•	•	•	•	•	•	•	•
Wiper/Washer/Headlight washer – check adjust. and function	•	•	•	•	•	•	•	•	•	•	•
Tires and Spare – check condition, pressure	•	•	•	•	•	•	•	•	•	•	•
Tires – rotate	•										
Service Reminder Display – reset	•	•	•	•	•	•	•	•	•	•	•
Road Test	•	•	•	•	•	•	•	•	•	•	•
Cooling System – check level, add if necessary		•		•		•		•		•	
Exhaust System – check for damage, leaks		•		•		•		•		•	
Engine OBD – check memory, purge		•		•		•		•		•	
Engine – check for leaks		•		•		•		•		•	
Battery – check electrolyte, add if necessary		•		•		•		•		•	
Dust and Pollen Filter – replace		•		•		•		•		•	
Automatic Transmission and Final Drive – check for leaks		•		•		•		•		•	
Manual Transmission and Final Drive – check for leaks		•		•		•		•		•	
Sunroof – clean, lubricate rails		•		•		•		•		•	
Front Axle – check dust seals, ball joints, tie rods, tie rod ends		•		•		•		•		•	
Tire Repair Set – check renewal date		•		•		•		•		•	
Lights – check		•		•		•		•		•	
Headlights – inspect, adjust if necessary		•		•		•		•		•	
Brake System – check		•		•		•		•		•	
Drive Shaft Boots – check		•		•		•		•		•	
Door Hinge Mechanisms – lubricate		•		•		•		•		•	
Spark Plugs – replace (except allroad 4.2L)				•				•			
Spark Plugs – replace (allroad 4.2L)						•					
Multitronic™ Transmission – change ATF				•				•			
Power Steering Fluid – check, add if necessary				•				•			
Air Cleaner – clean housing, replace filter element				•				•			
Ribbed Belt – replace (except 3.0)								•			
Ribbed Belt – check (3.0)								•			
Timing Belt – replace (3.0 and 4.2L)								•			
Timing Belt and tensioner – replace (2.7T)								•			

Brake Fluid – replace every 2 years, regardless of mileage



2004 Maintenance Schedule A8L

	Miles Kilometers	5 8	15 25	25 40	35 55	45 70	55 85	65 100	75 115	85 130	95 145
Engine Oil – change oil and replace filter		•	•	•	•	•	•	•	•	•	•
Wiper/Washer/Headlight washer – check adjust. and function		•	•	•	•	•	•	•	•	•	•
Tires and Spare – check condition, pressure		•	•	•	•	•	•	•	•	•	•
Tires – rotate		•									
Service Reminder Display – reset		•	•	•	•	•	•	•	•	•	•
Road Test		•	•	•	•	•	•	•	•	•	•
Cooling System – check level, add if necessary			•		•		•		•		•
Exhaust System – check for damage, leaks			•		•		•		•		•
Engine OBD – check memory, purge			•		•		•		•		•
Engine – check for leaks			•		•		•		•		•
Battery – check electrolyte, add if necessary			•		•		•		•		•
Dust and Pollen Filter – replace			•		•		•		•		•
Automatic Transmission and Final Drive – check for leaks			•		•		•		•		•
Sunroof – clean, lubricate rails			•		•		•		•		•
Front Axle – check dust seals, ball joints, tie rods, tie rod ends			•		•		•		•		•
Tire Repair Set – check renewal date			•		•		•		•		•
Lights – check			•		•		•		•		•
Headlights – inspect, adjust if necessary			•		•		•		•		•
Brake System – check			•		•		•		•		•
Drive Shaft Boots – check			•		•		•		•		•
Door Hinge Mechanisms – lubricate			•		•		•		•		•
Spark Plugs – replace							•				
Power Steering Fluid – check, add if necessary					•				•		
Air Cleaner – clean housing, replace filter element							•				
Timing Belt – replace									•		

Brake Fluid – replace every 2 years, regardless of mileage



2004 Maintenance Schedule TT Coupe and Roadster

	Miles	5	15	25	35	45	55	65	75	85	95
Kilometers	8	25	40	55	70	85	100	115	130	145	
Engine Oil – change oil and replace filter	•	•	•	•	•	•	•	•	•	•	•
Wiper/Washer/Headlight washer – check adjust. and function	•	•	•	•	•	•	•	•	•	•	•
Tires and Spare – check condition, pressure	•	•	•	•	•	•	•	•	•	•	•
Tires – rotate	•										
Service Reminder Display – reset	•	•	•	•	•	•	•	•	•	•	•
Road Test	•	•	•	•	•	•	•	•	•	•	•
Cooling System – check level, add if necessary		•		•		•		•		•	
Exhaust System – check for damage, leaks		•		•		•		•		•	
Engine OBD – check memory, purge		•		•		•		•		•	
Engine – check for leaks		•		•		•		•		•	
Battery – check electrolyte, add if necessary		•		•		•		•		•	
Dust and Pollen Filter – replace		•		•		•		•		•	
Automatic Transmission and Final Drive – check for leaks		•		•		•		•		•	
Manual Transmission and Final Drive – check for leaks		•		•		•		•		•	
Haldex Clutch – change oil		•		•		•		•		•	
Haldex Clutch – change filter				•				•			
Front Axle – check dust seals, ball joints, tie rods, tie rod ends		•		•		•		•		•	
Tire Repair Set – check renewal date		•		•		•		•		•	
Lights – check		•		•		•		•		•	
Headlights – inspect, adjust if necessary		•		•		•		•		•	
Brake System – check		•		•		•		•		•	
Drive Shaft Boots – check		•		•		•		•		•	
Door Hinge Mechanisms – lubricate		•		•		•		•		•	
Spark Plugs – replace				•				•			
Direct Shift Gearbox (DSG) – change oil and replace filter (VR6)				•				•			
Power Steering Fluid – check, add if necessary				•				•			
Air Cleaner – clean housing, replace filter element				•				•			
Ribbed Belt – replace (1.8T)								•			
Ribbed Belt – check (VR6)								•			
Timing Belt – replace (1.8T)								•			

Brake Fluid – replace every 2 years, regardless of mileage