



1999 Maintenance Schedule

	Miles	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100	105	1068		
	Kilometers	8	16	24	32	40	48	56	64	72	80	88	96	104	112	120	128	136	144	152	160	168			
TDI																									
Engine Oil – change		•	•		•		•		•		•		•		•		•		•		•		•		
Engine Filter – change		•	•		•		•		•		•		•		•		•		•		•		•		
Water Sep. – drain		•	•		•		•		•		•		•		•		•		•		•		•		
Timing Belt – check condition		•	•		•		•		•		•		•		•		•		•		•		•		
Fuel Filter – replace					•				•				•				•				•		•		
Timing Belt – replace**													•												
Timing Belt Tensioner – replace***													•												
1.8T																									
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
Engine Filter – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
V-Belt – replace																								•	
Spark Plugs – replace																								•	
Timing Belt – check condition																								•	
Timing Belt – replace																								•	
Timing Belt Tensioner – replace																								•	
2.0																									
Engine Oil – change		•	•		•		•		•		•		•		•		•		•		•		•	•	
Engine Filter – change		•	•		•		•		•		•		•		•		•		•		•		•	•	
Spark Plugs – replace (all but New Beetle)					•				•				•				•				•		•	•	
Spark Plugs – replace (NB)																								•	
Timing Belt – check condition																								•	
VR6																									
Engine Oil – change		•	•		•		•		•		•		•		•		•		•		•		•	•	
Engine Filter – change		•	•		•		•		•		•		•		•		•		•		•		•	•	
Spark Plugs – replace																								•	
V6																									
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Engine Filter – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Spark Plugs – replace																								•	
Timing Belt – check condition																								•	
Timing Belt – replace																								•	
Timing Belt Tensioner – replace																								•	
All Cars																									
W/W Fluid – check level			•		•		•		•		•		•		•		•		•		•		•	•	
Auto-Shift Lock – check			•		•		•		•		•		•		•		•		•		•		•	•	
Brake System – check			•		•		•		•		•		•		•		•		•		•		•	•	
Wheels – rotate front to rear			•		•		•		•		•		•		•		•		•		•		•	•	
Battery – check electrolyte level					•				•				•				•				•			•	
Dust Pollen Filter – replace					•				•				•				•				•			•	
Manual Trans. – check for leaks					•				•				•				•				•			•	
Automatic Trans. – check for leaks					•				•				•				•				•			•	
Tires/Spare – check condition					•				•				•				•				•			•	
Drive Shafts – check boots					•				•				•				•				•			•	
OBD – check DTC memory					•				•				•				•				•			•	
Door Check Straps – lubricate					•				•				•				•				•			•	
During Road Test					•				•				•				•				•			•	
After Road Test					•				•				•				•				•			•	
Air Cleaner* – replace filter																								•	
Cooling System – check level					•				•				•				•				•			•	
V-Belt – check tension/condition																								•	
Ribbed Belt – check condition																								•	
Front Axle – check																								•	
Check ATF and diff. level																								•	
Headlights – adjust					•				•				•				•				•			•	

*Every 40,000 miles and 4 years; except Passat and EuroVan, every 2 years **Recommended ***Recommended; replace once only
 Brake Fluid – change every 2 years regardless of mileage
 Air Bag System – check for function and damage after 4 years, 8 years and every 2 years thereafter