



2001 Maintenance Schedule

	Miles	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100	105			
	Kilometers	8	16	24	32	40	48	56	64	72	80	88	96	104	112	120	128	136	144	152	160	168			
TDI																									
Engine Oil – change		•	•		•		•		•		•		•		•		•		•		•		•		
Engine Filter – change		•	•		•		•		•		•		•		•		•		•		•		•		
Water Sep. – drain		•	•		•		•		•		•		•		•		•		•		•		•		
Timing Belt – check condition		•	•		•		•		•		•		•		•		•		•		•		•		
Fuel Filter – replace					•				•				•				•			•			•		
Timing Belt – replace									A				M				A								
1.8T																									
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
Engine Filter – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
Spark Plugs – replace									•									•						•	
V-Belt – replace																		•							
Timing Belt – check condition									•									•							
Timing Belt – replace																							•		
Timing Belt Tensioner – replace																								•	
2.0																									
Engine Oil – change		•	•		•		•		•		•		•		•		•		•		•		•		
Engine Filter – change		•	•		•		•		•		•		•		•		•		•		•		•		
Spark Plugs – replace (Cabrio)					•				•				•				•			•				•	
Spark Plugs – replace (except Cabrio)									•				•				•			•				•	
Timing Belt – check condition									•				•				•			•				•	
VR6																									
Engine Oil – change		•	•		•		•		•		•		•		•		•		•		•		•		
Engine Filter – change		•	•		•		•		•		•		•		•		•		•		•		•		
Spark Plugs – replace									•				•				•			•				•	
V6																									
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Engine Filter – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Spark Plugs – replace									•				•				•			•				•	
Timing Belt – check condition									•				•				•			•				•	
Timing Belt Tensioner – replace																								•	
Timing Belt – replace																								•	
All Cars																									
W/W Fluid – check level			•		•		•		•		•		•		•		•		•		•		•		•
Auto-Shift Lock – check operation			•		•		•		•		•		•		•		•		•		•		•		•
Brake System – check			•		•		•		•		•		•		•		•		•		•		•		•
Wheels – rotate from front to rear			•		•		•		•		•		•		•		•		•		•		•		•
Air Bag System – check function/damage*			•		•		•		•		•		•		•		•		•		•		•		•
Battery – check electrolyte level			•		•		•		•		•		•		•		•		•		•		•		•
Dust Pollen Filter – replace					•				•				•				•			•				•	
Cooling System – check level					•				•				•				•			•				•	
Manual Transmission – for leaks					•				•				•				•			•				•	
Automatic Transmission – for leaks					•				•				•				•			•				•	
Tire/Spare Tire – check condition					•				•				•				•			•				•	
Drive Shafts – check boots					•				•				•				•			•				•	
OBD – check DTC memory					•				•				•				•			•				•	
Door Hinge					•				•				•				•			•				•	
Headlights – check and adjust if necessary					•				•				•				•			•				•	
Road Test – during					•				•				•				•			•				•	
Road Test – after					•				•				•				•			•				•	
Air Cleaner – replace filter**									•				•				•			•				•	
V-Belt – check tension/condition									•				•				•			•				•	
Ribbed Belt – check condition									•				•				•			•				•	
Brake Fluid***									•				•				•			•				•	
Check ATF and diff. level									•				•				•			•				•	
Front Axle (tie rods, etc.)									•				•				•			•				•	

*Check the air bag system every 12 months, regardless of mileage. Check the air bag system at 4 years, 8 years, and then every 2 years (10, 12, 14, etc.)

**Replace the air filter every 2 years or 40,000 miles, whichever occurs first: Cabrio, Passat, EuroVan. Replace the air filter every 4 years or 40,000 miles, whichever occurs first: Golf, Jetta, New Beetle

***Replace the brake fluid every 2 years, regardless of mileage