

**Tech Article Title****Author****Date****S4 to RS4-look Bumper Conversion**[David](#)

2002

## Tools and products used:

X-acto knife w/various blades, fine toothed saw, drill, sheet metal cutters, sand paper of various grades, sanding block, two-part liquid epoxy, two-part clay epoxy, rasp, files, cable ties, primer, spot putty, metal mesh

## Bumper parts

8D0-807-103J GRU

S4 FRONT BUMPER \$383.95

8D0-807-977 GRU Lic plate trim \$50.50

8D0-807-345-L-GRU

Left Grill \$20.30

8D0-807-346-L-GRU

Right Grill \$20.30

Start with one of the side grilles . This way if you mess one up it will be cheaper than the bumper to replace.



Look at the back side of the grille and see where the black grille insert is held on by melted tabs. Remove these tabs by cutting or grinding them off. Remove insert from grille.



Cut center bar from the grille frame. Make sure you cut close enough to eliminate the flaired contours where they meet the edges. Take the center bar you just removed and cut a slat that will be big enough to cover the holes you just made in the frame.



Rough up the slats you just made and the backside of the frame on each side of the holes you made.



Use the liquid two part epoxy to attach the slats to the frame. This will give you back some of the rigidity you lost when you removed the center bar. Set them aside for 24hrs.



After the above has cured, take some of the two-part clay epoxy and fill the holes on the frame. Make sure you have enough epoxy so that it is a little higher/thicker than the surrounding frame. Also wrap some of it around the backside over the slat you epoxied on earlier. Let it cure for at least the time specified on the package. Once the above has cured, use a rasp to remove the bulk of the epoxy to get it close to the shape of the frame you are trying to match. Finish with finer toothed files and sand paper until you have matched the frame's contours.

Prime the area and let it dry. Check to see if any areas need to be addressed. High areas can be sanded more, low areas can be filled with more epoxy, once the area is sanded free of primer, and the above step repeated.




Small pin holes can be filled with spot putty and left to dry and resanded again. Prime and recheck and repeat any of the above steps until the desired results are achieved.



Set aside until dry.






Take the frame and the mesh of choice. Lay the mesh on the backside of the grille and trace the outline of the grille onto the mesh and cut out. Give yourself some extra, which will be cut down later.





Take some of the center bar removed at the beginning and cut sections off that resemble the letter "J" .



You will epoxy these to the outer edge of the frame on the backside to use as attachment points for the mesh. Lay the mesh on the backside of the grille frame and line up as desired. Mark places on the frame that would line up with the mesh and could be used as attachment sites (make sure these sites will not interfere with the grille's mounting tabs). Trim the "J"s you made earlier until they are shorter than the height of the grille edge. Also remove some of the material from the "J" until it looks like an "L".

Take the "L"s", roughen the attachment points, and epoxy them to the pre-chosen areas with the liquid two-part epoxy. Let it cure for 24hrs.



Drill a hole into each of the "L's" large enough for a small cable tie to pass through. Lay mesh on grille frame and attach with cable ties. Mark excess areas of the mesh to be cut off. Remove cable ties. Cut off excess mesh.

Repeat the above for the remaining grille and bumper. Once done, remove cable ties, dress the cut edges of the mesh with a file until they are no longer sharp. Paint or powder coat mesh. Install once everything else has been painted.



Done



Painted parts.



Finished product.

With thanks going to Katana for answering some questions.

---

[Terms of Use](#) | Copyright © 1996-2007 by AudiWorld. All rights reserved.